



## Inductive Neck Loop

RF-NL1

The Inductive Neck Loop is a compact listening device compatible with our RF-RX1 Portable Radio Frequency Receiver. When connected to the receiver, the RF-NL1 will produce a magnetic field that lets users with Telecoil-enabled hearing instruments receive the sound directly in their hearing aids.

### Physical Data

Dimensions	Loop Cable Length - 800mm (31.5") Loop Cable Diameter - 4mm (0.15") Cord Cable Length - 450mm (17.7") Cord Cable Diameter - 3mm (0.12")
Weight	57g (0.12lbs)
Finish	Black

### Technical Data

Connection	3.5mm plug (stereo)
Input Power	250mW

### Applications

For use in any situation where radio frequency systems provide listeners with clear sound:

- Conferences
- Cinemas and Theatres
- Courts
- Lecture Halls, Schools and Universities
- Places of Worship
- Museums
- Historical Sites
- Meeting Rooms

Talk to us now:  
+44 (0) 1732 223900 (UK & ROW)  
+1 616 392 3400 (US & Canada)  
[www.contacta.co.uk](http://www.contacta.co.uk)

